



Terrawagen

VANAGON / TRANSPORTER REAR FLARES INSTALL



<---Vanagon Fender Flare Kit Installation Video Here!

16" Fender Flare Cut Video Here --->



Watch this first!

STEP 1: Required tools, jack, jack stand, drill with a Phillips bit, masking tape



A) Raise vehicle and remove wheel, use jack stand!



STEP 2: FLARE INSTALLATION

B) Test fit part and hold in place using masking tape.



A) Use drill and self-tapping screws to attach flare to wheel opening.



B) Remove tape, Installation complete!

VANAGON / TRANSPORTER FRONT FENDER FLARE KIT

INSTALLATION INSTRUCTIONS:

Starting with lower door section. Align part with body trim line.

Hold part to body with masking tape. Drive screws into body with drill.

UPPER DOOR SECTION:

With door closed, place flare over the fender lip and hold in place with masking tape as shown.



Align edge of flare with edge of door lip. Drive screws into underside of door with drill.



Thanks for buying our product!